







Инструкция за монтаж на
бебешка кошара-люлка UNIKORN




Списък с елементи


 4 бр.	 16 бр.	 16 бр.	 12 бр.	 16 бр.
031	114	113	020	002
M6*15	3.5*18 MM			
6.3*13 MM	8X30			
2 бр.	38 бр.		4 бр.	12 бр.
120	004		271	317
 2 бр.	 2 бр.	 38 бр.	 4 бр.	 12 бр.
239	406	004	271	317
M8*6,5 MM				
12 бр.	4 бр.	8 бр.	1 комплект	1 бр.
 12 бр.	 4 бр.	 8 бр.	 1 комплект	 1 бр.
097	131	116	039	557
4*45	4 MM	M6*25	18*35 MM Ø8 MM	8 715 MM
9 бр.	1 бр.	4 бр.	1 комплект	2 бр.
357	172	105		
 2 бр.	 2 комплекта	 2 бр.		







 1 бр.	 1 бр.	 4 бр.
499	500	104
		M4*25 MM




NO	БРОЙ	РАЗМЕР	NO	БРОЙ	РАЗМЕР
01	1	1000 X 806	11	1	1260 X 590
02	1	1000 X 806	12	2	618 X 189
03	2	1304 X 175	14	2	400 X 120
04	1	1304 X 651	15	2	400 X 120
05	1	480 X 240	16	2	541 X 120
06	1	1250 X 709	17	2	551 X 387
07	1	572 X 202	18	1	1294 X 478
08	1	572 X 202			
09	1	572 X 202			
10	1	1260 X 202			











7




8




9


ARKA YÜZEYDEN




10




11




12




13



14



15



16