







Инструкции за монтаж на детска етажерка за книги RIGA






Списък с елементи


002  16 бр.	001 6 MM  16 бр.	004 8x30  16 бр.	200  48 бр.	120 6.3*13 MM  48 бр.
022  2 бр.	183  1 бр.	092 4*18 MM  12 бр.	670  1 бр.	533 3,9*28 MM  2 бр.
 6 бр.	114 M6*15 MM  18 бр.	011 3.5x25 MM  24 бр.	020  16 бр.	131  1 бр.







NO	БРОЙ	РАЗМЕР	NO	БРОЙ	РАЗМЕР	NO	БРОЙ	РАЗМЕР
01	1	1550 X 340						
02	1	1550 X 340						
03	1	1550 X 340						
04	1	1550 X 340						
05	1	894 X 341						
06	1	894 X 341						
07	4	324 X 200						
08	4	324 X 320						
09	4	300 X 300						
10	1	1544 X 296						
11	1	1561 X 211						
12	1	1561 X 331						
13	1	1561 X 311						






















665		6x
114		18x











- | | | | |
|-----|--|-----|---|
| 020 |  | 002 |  |
| | 4x | | 4x |
| | | 001 |  |
| | | | 4x |
| | | 004 |  |
| | | | 4x |




3











002		8x
001		8x
004		8x
020		8x




200		48x
120		48x






8




183




2x

022




1x

092




12x

670



1x

533



2x

